

Great Lakes Series MICHIGAN BEDSIDE CABINETS



Three drawer -

Features:

- Seamless 3/4" KYDEX® thermoformed tops.
- Rigid thermoformed door and drawer fronts on MDF core, woodgrain 2-sides and matching edgeband.
- Vented back panels are white melamine 2-sides on 3/4" particleboard core with edgeband.
- 6" deep removable plastic drawer liners. The removable plastic liners are extremely durable and make the stands easy to clean.
- Epoxy-coated drawer slides.
- 1.5" concealed dual casters are standard, with 2 or 4 premium 5/8" non-marring glides optional.
- All components are field replaceable.
- Ships fully assembled in recyclable packaging.



1-drawer/1-door



1-drawer/open-shelf

Specifications:

- Width: 19in (49cm)
- Depth: 18.5in (47cm)
- Height: 30in (76cm)
- Weight: 67lbs
- Cubic feet: 11

Configurations:

3-drawer, 1-drawer/1-door, 1-drawer/open-shelf

Options:

- A secondary top or spill containment top is available.
- Various hardware options available.
- Standard wood grain colors available, contact us about custom colors.

Manufactured in the USA.